

REIBAHLE FÜR ABS-SENSOR / ABS-reamer


Zur Reinigung der Führungsbohrung
To clean the ABS-sensor hole



Zur Reinigung der Führungsbohrung des ABS-Sensors im Radlagergehäuse, von Rost, Schmutz, Korrosion, etc.. Bei Anwendung des Werkzeuges keine Beschädigung des Neuteiles durch unsachgemäßes Einschlagen, Einpressen etc. Gewährleistung exakter Messwerte durch sauberen und korrekten Sitz des neuen Sensors. Durch integrierte, abgewinkelte, feinstverzahnte Spezialknarre nur Rechtsdrehung möglich. DBGM



To clean rust and oxidation of the ABS-Sensor hole at the wheel bearing housing. This tool avoids that ABS-Sensors will break at installing process. Ensures exact measuring results, based on perfect fitting sensor seat. Integrated ratchet wrench.



Nr. 456 150

Code: OE880000088

Nr. 456 180

Code: OE860000088

Nr. 456 181

Code: OE890000089

Reibahle für ABS-Sensor Ø15x23mm / ABS-reamer Ø 15x23mm

Reibahle f. VAG Ø18x23mm / ABS-reamer VAG Ø18x23mm

Reibahle f. Audi A4/A6 Ø18x34mm / ABS-reamer Audi A4/A6 Ø18x34mm